


BINOCULARS/BINOCULARES/
JUMELLES/BINÓCULO

ACULON T01 8x21 / 10x21

Instruction manual / Manual de instrucciones /
Mode d'emploi / Manual de instruçõesEn | Es
Fr | Pt

Nomenclature	Nomenclatura	Nomenclature	Nomenclatura
① Eyepieces	① Oculares	① Oculares	① Lentes oculares
② Eye cups*	② Ojeras*	② Ojeras*	② Oculares*
③ Dipter ring	③ Anillo de dioptrías	③ Anillo de dioptrías	③ Anel de dioptria
④ Focusing ring	④ Anillo de enfoque	④ Bague de mise au point	④ Anel de foco
⑤ Objective lens	⑤ Lente del objetivo	⑤ Objetivo	⑤ Objetivo
⑥ Interpupillary distance	⑥ Distancia interpupilar	⑥ Distancia interpupilar	⑥ Distância interpupilar
⑦ Wriststrap eyecups	⑦ Ojales para la correa de muñeca	⑦ Círculos	⑦ Passadores da alça de pulso
* Eye cups	* Ojeras	* Oculares	* Oculares
• For eyeglass wearers, use eye cups in the fully retracted position.	• Si lleva gafas, coloque las ojeras en la posición plegada por completo.	• Para portadores de lentes, use los ojales en posición totalmente retraída.	• Para pessoas que usam óculos: use os oculares na posição totalmente retraída.
• Non-eyeglass wearers, use eye cups in the fully extended position.	• Si no lleva gafas, coloque las ojeras en la posición extendida por completo.	• Los portadores de lentes pueden utilizar los ojales en posición completamente retráctil.	• Para pessoas que não usam óculos: use os oculares na posição totalmente estendida.




Fig. 1/Fig. 1/Fig. 1/Fig. 1

English

PRECAUTIONS

Thank you for purchasing these Nikon binoculars.

Strictly observe the following guidelines in order to use the equipment properly and avoid potentially dangerous accidents.

1 Before using the product, thoroughly read the "SAFETY PRECAUTIONS", "OPERATION PRECAUTIONS" and the instructions accompanying the product on correct use.

2 Keep these instructions within easy reach for reference.

In order to protect you and third parties from possible injury and/or property damage or loss, you are kindly requested to pay close attention to all instructions, warnings and cautions regarding the use and care of this product.

WARNING

This indication alerts you to the fact that any improper use ignoring the contents described herein can result in potential death or serious injury.

CAUTION

This indication alerts you to the fact that any improper use ignoring the contents described herein can result in potential injury or may cause only physical damage.

OPERATION PRECAUTIONS

The contents in this section alert you to the fact that any improper use ignoring the contents described herein may negatively affect product performance and functionality.

SAFETY PRECAUTIONS

WARNING!

Never look at the sun directly while using binoculars/monocular.

Looking directly at the sun or intense light may seriously damage the eyes or cause blindness.

CAUTION!

• Do not leave the binoculars/monocular in an unstable place. They may fall and cause injury.

• Do not walk through the binoculars/monocular while walking. You may walk into unexpected objects and get hurt.

• Do not swing the binoculars/monocular by their straps. They may hit someone and cause injury.

• The soft case, strap, and external materials utilized on binoculars/monocular and eyecups may deteriorate due to aging and stain clothes. To prevent this, check their condition before each use, and consult with a Nikon authorized service representative if such deterioration is found.

• If you use the eyecups for a long period of time, you may suffer skin inflammation. If you develop any symptoms, stop use and consult a doctor immediately.

• Be careful not to pinch your finger when adjusting interpupillary distance or diopter. Be particularly careful if you let small children use the binoculars.

• Do not leave the polystyrene bag used for packaging within small children's reach. Children may put it in their mouths and suffocate.

• Be careful that small children do not inadvertently swallow the cap or eyecup. If it does happen, consult a doctor immediately.

• Do not disassemble the binoculars/monocular. Repair should be referred to a Nikon authorized service representative.

OPERATION AND CONTROLS

• Do not open the right and left binocular tubes beyond their limits. Also be careful not to rotate the diopter ring and focusing ring beyond their limits.

• Avoid rain, water splashes, sand, mud.

• Always protect binoculars/monocular from shock. If you cannot obtain a normal image after dropping or getting the binoculars/monocular wet, take them immediately to a Nikon authorized service representative.

• When exposed to sudden temperature changes, water condensation may occur on lens surfaces. In this case, thoroughly dry the binoculars/monocular at room temperature.

STORAGE

- Water condensation or mold may occur on lens surfaces because of high humidity. Therefore, store the binoculars/monocular in a cool, dry place. After use on a rainy day or at night, thoroughly dry them at room temperature, then store in a cool, dry place.
- For long term storage, keep binoculars/monocular in a plastic bag or an airtight container with a desiccant. If this is not possible, store in a clean, well-ventilated place, separate from the case, as they are easily affected by moisture.
- Do not leave the binoculars/monocular in a car on a hot or sunny day, or near heat generating equipment. This may damage or negatively affect them.

MAINTENANCE & STORAGE

1. Remove dust trapped in the focusing ring, diopter ring, or other rotating parts with a soft brush.
2. After having removed dust with a blower, clean the body surface using a soft, clean cloth with water and wipe off salt that may be on the body surface. Then wipe the body surface with a dry cloth. Do not use benzene, thinner, or other organic solvent.
3. When removing dust on the lens surface, use a soft oil-free brush.
4. When removing stains or smudges like fingerprints from the lens surfaces, wipe the lenses very gently with a soft clean cotton cloth. Use a small quantity of pure alcohol (ethanol) or lens cleaner available in stores to wipe stubborn smudges, from the center of the lens to the outside in a circular motion. Do not use anything hard as it may scratch the lens surface.

SUPPLIED ITEMS

- Binocular x 1
- Soft case x 1
- Wrist strap x 1
- Eye piece cap x 2

Note: Objective lens caps are not included.

OPERATION

1) Adjusting interpupillary distance

While looking at a subject through the ① Eye pieces, gently rotate the binocular body until the two images of the subject become one (Fig. 1).

2) Diopter adjustment

(Balancing right and left eyepiece)

1. Rotate the ④ Focusing ring until you obtain a sharp image of your subject in the left eye.
2. Rotate the ③ Diopter ring of the right eyepiece until you obtain a sharp image of the same subject in the right eye.
- * For focusing with the ③ Diopter ring or ④ Focusing ring, rotate counter-clockwise to focus on a nearby subject, or clockwise for a distant subject.
- * With the focus correctly adjusted, record the ③ Diopter ring index position for easier future diopter adjustment.

3) Focusing

When you view a different subject, adjust the ④ Focusing ring until you obtain a sharp image.

SPECIFICATIONS

Type	Roof-prism central focusing type	
Model	ACULON T01 8x21	ACULON T01 10x21
• Magnification	(x8)	(x10)
• Effective diameter of objective lens	(mm) 21	(mm) 21
• Real field of view	(°) 6.3	(°) 5.0
• Angular field of view (apparent)	(°)* 47.5	(°) 47.2
• Field of view at 1,000m	(ft) 330	(ft) 262
• (m)	110	87
• Exit pupil	(mm) 2.6	(mm) 2.1
• Relative brightness	6.8	4.4
• Eye relief	(mm) 10.3	(mm) 8.3
• Close focusing distance	(ft)** 9.8	(ft)** 9.8
	(m) 3.0	(m) 3.0
• Length	(in) 3.4	(in) 3.4
	(mm) 87	(mm) 87
• Width	(in) 4.1	(in) 4.1
	(mm) 104	(mm) 104
• Thickness	(in) 1.3	(in) 1.3
	(mm) 34	(mm) 34
• Weight	(oz) 6.9	(oz) 6.9
	(g) 195	(g) 195
• Interpupillary distance adjustment	(mm) 56-72	(mm) 56-72

* The number calculated by the formula $\tan u' = f \times \tan u$

** Apparent field of view: 2.4 ft. Magnification: 1. Real field of view: 2.4

** With normal eyesight without accommodation

Español

PRECAUCIONES

Gracias por adquirir estos binoculares Nikon.

Siga atentamente estas directrices para utilizar el equipo adecuadamente y evitar problemas potencialmente peligrosos.

- 1 Antes de utilizar este producto, lea detenidamente las "PRECAUCIONES DE SEGURIDAD", "PRECAUCIONES DE FUNCIONAMIENTO" y las instrucciones sobre el uso correcto que se incluyen con el producto.

- 2 Mantenga estas instrucciones para consultarlas siempre que sea necesario.

Para evitar que tanto usted como cualquier otra persona puedan sufrir daños o pérdidas materiales, le pedimos que preste especial atención a todas las instrucciones, advertencias y precauciones relativas al uso y cuidado de este producto.

ADVERTENCIA

Esta indicación le advierte sobre el hecho de que cualquier uso indebido que ignore el contenido aquí descrito, puede ocasionar posibles lesiones graves o incluso la muerte.

PRECAUCIÓN

Esta indicación le advierte sobre el hecho de que cualquier uso indebido que ignore el contenido aquí descrito, puede ocasionar posibles lesiones graves o provocar solo daños físicos.

PRECAUCIONES DE FUNCIONAMIENTO

Los elementos de esta sección le advierten sobre el hecho de que cualquier uso indebido que ignore el contenido aquí descrito, puede afectar negativamente al rendimiento y funcionalidad del producto.

PRECAUCIONES DE SEGURIDAD

ADVERTENCIA!

Nunca mire directamente al sol a través de estos binoculares/monocular.

Mirar directamente al sol o una luz intensa podría provocar daños graves en la visión o ceguera permanente.

PRECAUCIÓN!

No deje los binoculares/monocular en un lugar inestable. Pueden caerse y provocar heridas.

• No mire a través de los binoculares/monocular mientras camina. Podría tropezarse con algo y sufrir algún daño.

• No sujeté los binoculares/monocular por la correa y los balances como si fueran un pétalo. Puede golpear a alguien y herirlo.

• El estuche blando, la correa y los materiales extremos utilizados en los binoculares/monocular, así como en las ojeras, pueden deteriorarse con el tiempo y manchar la ropa. Para evitarlo, compruebe su estado antes de cada utilización y póngase en contacto con un representante del servicio técnico autorizado de Nikon si observa dicho deterioro.

• Si utiliza las ojeras durante mucho tiempo, puede notar una inflamación en la piel. Si presenta algún síntoma, deje de usarlo y pongase inmediatamente en contacto con un médico.

• Tenga cuidado de no pillar los dedos en la distancia interpupilar o configurar el ajuste de diópteros. Tenga especial cuidado si permite que los niños utilicen los binoculares.

• No deje la bolsa de polietileno utilizada para el embalaje al alcance de niños pequeños. Se podrían introducir en la boca y asfixiar.

• Intenta evitar que los niños pequeños ingieran accidentalmente la tapa o la jeringa. En caso de ingestión, pongase inmediatamente en contacto con un médico.

• No desmonte los binoculares/monocular. La reparación deberá realizarla únicamente un representante del servicio técnico autorizado de Nikon.

ENTRETIEN Y STOCKAGE

1. Elimine la posibilidad coincidir en la baguette de mise au point, la baguette dióptica o toute autre pièce mobile avec un pinceau doux.

2. Apres el écran de protection éliminer la posibilidad de que el sujeto pueda adherir a la superficie. Puede limpiar la superficie en la lente con un paño suave y limpio.

3. Evite que el agua, salpicaduras de agua, arena y polvo.

4. Proteja las jeringas de la humedad y el calor.

5. Proteja las jeringas de la humedad y el calor.

6. Proteja las jeringas de la humedad y el calor.

7. Proteja las jeringas de la humedad y el calor.

8. Proteja las jeringas de la humedad y el calor.

9. Proteja las jeringas de la humedad y el calor.

10. Proteja las jeringas de la humedad y el calor.

11. Proteja las jeringas de la humedad y el calor.

12. Proteja las jeringas de la humedad y el calor.

13. Proteja las jeringas de la humedad y el calor.

14. Proteja las jeringas de la humedad y el calor.

15. Proteja las jeringas de la humedad y el calor.

16. Proteja las jeringas de la humedad y el calor.

17. Proteja las jeringas de la humedad y el calor.

18. Proteja las jeringas de la humedad y el calor.

19. Proteja las jeringas de la humedad y el calor.

20. Proteja las jeringas de la humedad y el calor.

21. Proteja las jeringas de la humedad y el calor.

22. Proteja las jeringas de