


BINOCULAR INSTRUCTIONS


Congratulations on the purchase of your new Sightron Binocular. Sightron makes several types of precision binoculars for varied uses. These instructions will help you achieve maximum performance regardless of the model you have chosen. Should you ever need assistance in choosing the correct binoculars for a specific application, please contact our Customer Service Department at 1-919-562-3000 or you can email us at info@sightron.com.



EYE ADJUSTMENTS

Interpupillary distance (IPD) is the distance from the center of one eye to the other. To set the distance correctly hold your binocular in the correct viewing position and move the barrel until you see one circular field. Once you have achieved a perfect circular field note the IPD reading on your binocular for future quick adjustments.

Note: Compact binoculars do not have an IPD scale.




ADJUSTING YOUR EYECUPS


Sightron offers several types of eyecups depending on the model of binocular used. Adjusting your eyecups will allow people wearing glasses to achieve a full field of view that would otherwise be reduced. Please see the illustrations for proper eyecup adjustment on the various Sightron models.



SII Compact Series, eyecups fold up and down




SIII Compacts, SII Waterproof and SII Big Sky models, eyecups rotate up and down



SIII Standard Series, eyecups pull up and down

FOCUSING YOUR BINOCULAR

All Sightron Binoculars are adjustable for individual eye focus. To adjust for your eyes close your right eye and focus your left eye using the center focus wheel. Once the left eye is in focus, close the left eye and turn the right diopter until the right eye is in focus. Both eyes are now in focus, rotate the center focus wheel to adjust the focus for objects near or far until clear.



BINOCULAR CARE AND CLEANING

If you have purchased a waterproof model (SII Waterproof Series, SII Big Sky or SIII Series) your binocular is waterproof and fog proof and will provide many years of trouble free service. Non-Waterproof models are not fog-proof or waterproof and should not be used in conditions where water or harsh conditions will cause them to fog. It is best to store all binoculars in a safe clean environment where they will be free from excessive knocks and hard vibrations.

Never attempt to wipe mud or dirt from lenses as the grit will scratch the lenses and remove the lens coating from your binoculars. To clean use distilled alcohol or purchase a camera cleaning kit from your local department store. Never use a standard window cleaning solution as they will scratch the lenses. Never attempt to clean your binocular by removing lenses or disassembly.

CAUTION:

Never attempt to view the sun with your binocular or the naked eye, permanent injury and loss of sight may occur.

SIGHTRON, INC. PRODUCTS LIFETIME LIMITED WARRANTY

Sightron, Inc., will repair this product or replace the product, at Sightron's sole option, free of charge (except for a \$7.50 handling charge). This warranty only covers failure due to defects in materials or workmanship which occur during normal and regular use. It does not cover damage which occurs in shipment or failures which are not supplied by Sightron, Inc., or failures which result from accident, misuse, abuse, neglect, mishandling, misapplication, alteration, modification or service by anyone other than a Sightron, Inc. factory or authorized service center or damage that is attributable to acts of God.

There are no express warranties except as listed above. SIGHTRON, INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other legal rights which vary from state to state. If a problem with this product develops during or after the warranty period, you should contact Sightron, Inc. factory, your dealer or return your product with a brief explanation of the problem you are experiencing. Please include your complete shipping address and your daytime telephone number so we may contact you if necessary.

BINOCULAR FEATURES

Feature	SII Compact	SII Compact Waterproof	SII Waterproof	SII Big Sky	SIII Compact	SIII Standard
Coating Type	Multi	Multi	Multi	Fully-Multi	Fully-Multi	Fully Multi
Phase Coated	No	No	No	No	Yes	Yes
Tripod Adapter	No	No	Yes	Yes	No	Yes
IPD Scale	No	No	Yes	Yes	No	No
Prism Type	BAK-7	BAK-4	BAK-4	BAK-4	BAK-4/7	BAK-4/7
Diopter Adjustment	Right Eye	Right Eye	Right Eye	Right Eye	Right Eye	Right Eye
Eyecup Type	Rubber Folding	Twist-Up	Twist-Up	Twist-Up	Twist-Up	Pop-Up
Pouch	Yes	Yes	Yes	Yes	Yes	Yes
Binocular Strap	Yes	Yes	Yes	Yes	Yes	Yes
Waterproof	No	Yes	Yes	Yes	Yes	Yes
Climate Control Coating	No	No	No	Yes	No	No

SIGHTRON™

100 Jeffrey Way, Suite A
 Youngsville, NC 27596
 800.867.7512 919.562.7129
 www.sightron.com email: info@sightron.com